


**[FOR 22R-E]  
INSPECTION OF IGNITION COIL**


**1. DISCONNECT HIGH TENSION WIRE**



**2. MEASURE PRIMARY COIL RESISTANCE**

Using an ohmmeter, measure the resistance between the positive (+) and negative (–) terminals.

**Primary coil resistance (cold): 0.5 – 0.7  $\Omega$**




**3. MEASURE SECONDARY COIL RESISTANCE**

Using an ohmmeter, measure the resistance between the positive (+) terminal and high-tension terminal.

**Secondary coil resistance (cold): 11.4 – 15.6 k $\Omega$**

## INSPECTION OF IGNITER


### 1. TURN IGNITION SWITCH ON



### 2. CHECK POWER SOURCE LINE VOLTAGE

Using a voltmeter, connect the positive (+) probe to the ignition coil positive (+) terminal and the negative (-) probe to body ground.

**Voltage: Approx. 12V**




### 3. CHECK POWER TRANSISTOR IN IGNITER

(a) Using a voltmeter, connect the positive (+) probe to the ignition coil negative (-) terminal and the negative (-) probe to body ground.


**Voltage: Approx. 12V**

(b) Unplug the wiring connector from the distributor.



(c) Using a dry cell battery (1.5V), connect the positive (+) pole of the battery to the pink wire terminal and the negative (-) pole to the white wire terminal.

**CAUTION: Do not apply voltage more than 5 seconds to avoid destroying the power transistor in the igniter.**



(d) Using a voltmeter, connect the positive (+) probe to the ignition coil negative (-) terminal and the negative (-) probe to the body ground.


(e) Check the voltage reading.

**Voltage: 5 — 8V**

If a problem is found, replace the igniter.

### 4. TURN IGNITION SWITCH OFF

### 5. REMOVE TEST EQUIPMENT AND RECONNECT WIRING



## ON-VEHICLE INSPECTION OF DISTRIBUTOR


### 1. CHECK AIR GAP

- (a) Using a feeler gauge, measure the gap between the signal rotor and the pickup coil projection.

**Air gap: 0.2 — 0.4 mm (0.008 — 0.016 in.)**

- (b) Adjust the gap if necessary.

- Loosen the two screws and move the signal generator until the gap is correct. Tighten the screws and recheck the gap.




### 2. CHECK SIGNAL GENERATOR

Using an ohmmeter, check the resistance of the signal generator.

**Generator resistance: 140 — 180Ω**


If the resistance is not correct, replace the signal generator.



### 3. CHECK VACUUM ADVANCE (FOR 22R)

- (a) Disconnect the vacuum hose and connect a vacuum pump to the diaphragms.
- (b) Apply vacuum and check that the vacuum advance moves.

If the vacuum advance does not work, repair or replace as necessary.




### 4. CHECK GOVERNOR ADVANCE (FOR 22R)

- (a) Turn the rotor shaft clockwise, release it and check that the rotor returns slightly counterclockwise.
- (b) Check that the rotor shaft is not excessively loose.

## DISTRIBUTOR

### REMOVAL OF DISTRIBUTOR

1. DISCONNECT VACUUM HOSES (FOR 22R), HIGH TENSION CORDS AND WIRING CONNECTOR
2. REMOVE TWO SCREWS AND PULL OFF DISTRIBUTOR CAP
3. REMOVE HOLD-DOWN BOLT AND PULL OUT DISTRIBUTOR




### INSTALLATION OF DISTRIBUTOR


#### 1. INSTALL DISTRIBUTOR AND SET TIMING

- (a) Turn the crankshaft pulley until the timing mark is aligned with 0° TDC (22R) and 5° BTDC (22R-E) mark.

NOTE: Check that the rocker arms on the No.1 cylinder are loose. If not, turn the crankshaft one full turn.



- (b) Temporarily install the rotor.
- (c) Begin insertion of the distributor with the rotor pointing upward and the distributor mounting hole approximately at center position of the bolt hole.
- (d) When fully installed, the rotor will rotate to the position shown.



- (e) Align the rotor tooth with the pickup coil projection.
- (f) Coat the distributor set bolt with sealer and install the bolt. Torque the bolt.

**Torque: 220 kg-cm (16 ft-lb, 22 N·m)**

- (g) Install the rotor and distributor cap with wires.

#### 2. INSTALL FOLLOWING PARTS:

- (a) Vacuum hoses (for 22R)
- (b) Wiring connector

#### 3. ADJUST IGNITION TIMING

- (a) Connect a timing light to the engine.
- (b) Start the engine and run it at idle.
- (c) Using a timing light, slowly turn the distributor until the timing mark on the crankshaft pulley is aligned with the 12° mark. Tighten the distributor bolt.
- (d) Recheck the ignition timing.

**Ignition timing: 22R 0° TDC (Max. 950 rpm)**  
 (w/vacuum advance cut)  
**22R-E 5° BTDC at idle**  
 (short terminal "T")

